

Tools required:
 - 4mm hex key with ball end (included)
 - Wood block (included)
 - Sand Paper (included)
 - Mallet

DUO ADIRONDACK CHAIR

ASSEMBLY INSTRUCTIONS

1 Line up the holes on the backrest with the corresponding holes on the underside of the seat and secure the two assemblies together with the supplied M6x30 mm bolts.

2 Attach the side frame assemblies into the backrest and seat assembly, ensure the tenons and dowels are align correctly. Then secure the assemblies together with the supplied bolts and dowels.

3 There are 3 different length of dowels. Carefully check to ensure the correct dowels are used.

