

Tools required:  
- 4mm allen key (included)

# QUBE ALU SWIVEL ROCKER

## ASSEMBLY INSTRUCTIONS

Abrasion may damage the fabric.  
Do not place it on an abrasive surface  
such as a concrete floor

- 1 Line up the seat/back assembly with the 4 upper holes in the frames and secure them loosely in place (two turns only) with the special bolt.  
- Note that there must be spacer ring between the frame and the seat/back assembly.
- 2 Once all the bolts are fitted, tighten them fully.

