

KINGSLEY~BATE

Fine Garden Furniture

ASSEMBLY INSTRUCTIONS FOR THE TN-24P/44P/50P/51P/60P/73P/96P






TABLE TOP




HARDWARE



LEGS

STEP-I

Unpack, inspect and lay the parts on a clean, flat, soft surface to avoid marring the wood.



STEP-II

Carefully laying the TABLE TOP on a flat, smooth surface; match the numbers stamped on the LEGS to the corresponding numbers stamped on the corner blocks of the TABLE TOP, insert the LEGS into position as shown in the assembly

photographs. Slide the split washers followed by the flat washers onto the bolts and insert through the corner blocks and into the LEGS as shown.



STEP-III

Using the wrench provided, tighten the bolts slowly. Please take care not to over tighten as it may damage the item. Tighten until legs do not wobble; use of a power tool is NOT recommended. You should always

upright the table with 2 people, tilting the table on its side and putting the weight on 2 legs to upright could cause damage to the table. Lift table straight up, flip over and then set it down.

IF YOU HAVE ANY QUESTIONS REGARDING THE ASSEMBLY OF YOUR KINGSLEY-BATE FURNITURE, PLEASE CONTACT THE KINGSLEY-BATE DEALER NEAREST TO YOU OR KINGSLEY-BATE DIRECTLY. WE THANK YOU FOR CHOOSING OUR FURNITURE.

** KINGSLEY-BATE WILL NOT TAKE RESPONSIBILITY FOR DAMAGE
IF THESE INSTRUCTIONS ARE NOT FOLLOWED PROPERLY*