




**BEFORE YOU BEGIN,** make sure you have all parts and hardware listed below, then read all instructions.




SEAT ASSEMBLY  
1x



LEG ASSEMBLY  
1x




SWIVEL COVER  
1x



316 - 1/4 - 10 - 50HL  
4x


**NOTE:** Arms apply only to Arm Chair SKUs [360], [361], and [362]. Steps and hardware are identical for both Arm and Side Chairs.

1



PLACE THE SWIVEL COVER ON THE METAL SWIVEL PLATE, ROTATE IT TO ALIGN WITH THE LEG NOTCH, THEN SET THE SEAT ASSEMBLY ON TOP AND FASTEN THE FRONT CORNER THROUGH THE METAL PLATE, SWIVEL COVER, AND SEAT.

2



ROTATE THE SEAT ASSEMBLY 180 DEGREES AND FASTEN THE OPPOSITE CORNER. ROTATE AND FASTEN THE REMAINING CORNERS. TIGHTEN ALL CONNECTIONS, BUT DO NOT OVER-TIGHTEN AS THIS MAY DAMAGE THE PRODUCT.