



SEASIDE CASUAL (44,45) 3Ft, 4Ft Portsmouth Bench rev. A

Parts List:

- (1) Back Assembly
- (1) Seat Assembly
- (2) Side Leg Assemblies
- (2) Angle Seat Braces
- (45 Only) (1) Leg Stretcher



Hardware:

- (6) 3-1/2" Connector Bolts
- (6) Lock Washers
- (6) Flat Washers
- (6) Nuts
- (6) 3" Hex 1/4" Lags
- (45 Only) (8) 3" Hex 1/4" Lags
- (6) 5/8" Plugs
- (4) 1-3/4" Phillip's Head Screws

Tools Required:


- Phillip's Head Screwdriver
- 7/16 Socket or Wrench
- 4MM Allen Wrench (Included)

Assembly Instructions


Step One: Set Up

READ ENTIRE INSTRUCTIONS BEFORE BEGINNING! Carefully remove contents from box. Make sure that all parts and hardware are included.

Step Two: Side Leg Assembly



Place Seat Assembly face down on a flat clean surface. Place Side Leg Assembly along outside of the Seat Support, while aligning pre-drilled holes (Left Picture). Install using (2) 3-1/2" connector bolts. Finger tighten using flat & lock washers and nuts (Right Picture). Do not tighten at this time. Repeat process on other side.



Step Three: Back Assembly



Place Chair in standing position. Place Back Assembly aligning pre-drilled holes on both ends allow Back Assembly to lean against the ground. Attach using (2) 3-1/2" connector bolts. Finger tighten using flat & lock washers and nuts (Left Picture). Flip Back Assembly up into position. Attach to Seat Assembly using (6) 3" Hex 1/4" Lags (Right Picture). Do not tighten at this time.



Step Four: Angle Brace Assembly



Position Angle Brace over second slat from rear (Left Picture). Attach using (2) 1-3/4" Phillip's Head Screws. Repeat process for other brace.

Step Five: Front Leg Stretcher (45 Only)



Place Front Leg Stretcher along all Mid Leg Braces aligning pre-drilled holes. Attach using (2) 3" Hex 1/4" Lags.

Step Six: Tightening of Hardware

Tighten all connections. **Do not over tighten!!! Over tightening of hardware can cause damage to the item.** Plug all holes. Using (6) 5/8" Plugs.